#### **NAVCOM MARINE ELECTRONIC LTD.**

The Trust Company of the Marshall Islands Inc.

Trust Company Complex, Ajeltake Road, Ajeltake Island, Majuro Marshall Islands M1196960

Liaison Address: Postane Mah. Muhtar Rıfat Sok. No: 8 34940 Tuzla/İstanbul – TURKEY

Phone: +90 216 447 447 0-2 Fax: +90 216 447 447 4 Web: www.ecdissales.com / www.navcom.com.tr







# **INMARSAT-C SETTINGS**

Most sat-c terminals will use the same general setup instructions found here:

PLEASE FIND GENERAL INSTRUCTIONS FOR SAT-C SAC.

PLEASE SET UP AN ENTRY IN YOUR ADDRESS BOOK ON THE SATCOM-C TERMINAL UNDER NETWORK/SPECIAL FOR THE WLINK SAC (SPECIAL ACCESS CODE):

- ENTRY NAME: SHIPMAIL
- LESO IDS: AOR-W 002 or 012 AOR-E 102 or 112 POR 202 or 212 IOR 302 or 312
- SPECIAL ACCESS CODE NUMBER: WLINK (-- ALL UPPER CASE.
- SELECT TYPE: SPECIAL
- SELECT 5-BIT DATA FORMAT

THE ABOVE COMPLETES THE SET UP OF THE ADDRESS BOOK ENTRY. NOW YOU CAN USE THIS ENTRY FOR ALL YOUR INTERNET EMAIL, FAX, AND TELEX COMMUNICATIONS VIA SATCOM-C.

# **MESSAGE FORMAT:**

THE FOLLOWING IS AN EXAMPLE OF A COMPOSED MESSAGE ON THE TERMINAL TO BE SENT TO THE INTERNET EMAIL ADDRESS SUPPORT(AT)WLNET.COM, TO FAX NUMBER +15083707791, AND TO TELEX NUMBER 519402345.

SNIP SNIP
:SUPPORT(AT)WLNET.COM
:FAX15083707791
:TLX529402345
:BC:BILLING CODE
:RF:REFRENCE NUMBER
:DC:DEPARTMENT BILLING
:SU:SUBJECT LINE.

THIS IS THE	BODY OF THE MESSAGE	GOING FROM MY SA	ATCOM-C TERMINAL	VIA THE WLINK SAC
CODE. PLS.	CONFIRM RECEIPT. THIS	IS THE LAST LINE OF	MY MESSAGE.	

 SNI	Þ	SN	JID	
 SIVI	М	JI'	VIP.	

#### **NOTES:**

- A) ALL CONTROL LINES MUST START ON WITH A COLON:
- B) ONLY A SINGLE DESTINATION ADDRESS IS REQUIRED AT THE BEGINNING OF THE MESSAGE. BILLING CODE, REFERENCE NUMBER, DEPARTMENT BILLING CODE, AND SUBJECT LINES ARE OPTIONAL. THERE IS NO NEED TO PUT THE TO: FIELD INTO THE MESSAGE, ONLY: THEN THE ADDRESS, OR FAX, TLX, ETC.
- C) VESSEL WILL RECEIVE NON-DELIVERY NOTIFICATIONS ONLY WHEN A MESSAGE IS NOT DELIVERED TO ANY OF THE ADDRESSES.
- D) VESSEL WILL RECEIVE A CANCELLATION NOTIFICATION IN CASE A MESSAGE IS BADLY FORMED.

IF these do not work for the Captain, he likely has a Furuno Felcom-15 SAT-C Terminal. Please confirm this with him, and if that is the case, here are the felcom 15 instructions:

#### Furuno Felcom15:

Enter the WLINK SAC into the station list (one time only)

- 1. Press the F8 key to display the Setup menu.
- 2. Press the 9 key to display the Configuration menu.
- 3. Press the 1 key to display the Station List.
- 4. Press the down arrow key to place the cursor on a blank line.
- 5. Press the Enter key.
- 6. Press the Enter key to open the station group entry window.
- 7. Enter station group name, WLINK
- 8. Press the Enter key to close the window.
- 9. Press the Down Arrow key to choose Station Name.
- 10. Press the Enter key to open the station name entry window.
- 11. Enter station name, SHIPMAIL
- 12. Press the Enter key to close the window.
- 13. Press the Down Arrow key to choose Destination Type SPEC
- 14. Press the Enter key to open the destination type window.
- 15. Enter the Station ID as: WLINK (all capitals)
- 16. Press Enter key
- 17. Press the Esc key three times to return to the standby display.

# Prepare the message according to the World-Link Specifications, when ready send the message as follows:

- 1. Press the F3 key to display the Transmit menu.
- 2. Press the 1 key to display the Transmit Message menu.
- 3. Press the Down Arrow key twice to choose Station Name.
- 4. Press the Enter key to open the Station List.
- 5. Choose SHIPMAIL from the Station List

6. Choose LES AOR-W 002 or 012 AOR-E 102 or 112 POR 202 or 212 IOR 302 or 312

- 7. Choose Text coding format as desired, for 5-bit choose ITA2
- 8. Choose Confirmation OFF
- 9. Choose Transmit

## Felcom 16/18/19:

- 1. Press the [F8] key to display the Setup menu.
- 2. Press the [8] key to display the Configuration menu.
- 3. Press the [1] key to display the Station List.
- 4. Press the down arrow key to place the cursor on a blank line.
- 5. Press the Enter key.
- 6. Press the [Enter] key to open the station group entry window.
- 7. Enter station group name, WLINK
- 8. Press the [Enter] key to close the window.
- 9. Press the Down Arrow key to choose Station Name.
- 10. Press the [Enter] key to open the station name entry window.
- 11. Enter station name, SHIPMAIL.
- 12. Press the [Enter] key to close the window.
- 13. Press the Down Arrow key to choose Destination Type
- 14. Press the [Enter] key to open the destination type SPEC.
- 15. Press the Down or Up Arrow keys to choose destination type SPEC.
- 16. Press the [Enter] key to close the window.

# Prepare the message according to the World-Link Specifications, when ready send the message as follows:

- 1. Press the F3 key to display the Transmit menu.
- 2. Press the 1 key to display the Transmit Message menu.
- 3. Press the Down Arrow key twice to choose Station Name.
- 4. Press the Enter key to open the Station List.
- 5. Choose SHIPMAIL from the Station List

6. Choose LES AOR-W 002 or 012 AOR-E 102 or 112 POR 202 or 212 IOR 302 or 312

- 7. Choose Text coding format as desired, for 5-bit choose ITA2
- 8. Choose Confirmation OFF
- 9. Choose Transmit